Project navigation

Name | ↕^ | **Type**

Alarm2020.vlp
- ALARM-actions — FA **VMB4RYLD**
  - Buzzer — CH1 — Inhibited
  - Siren — CH2 — Forced off
  - PIR direct — CH3 — Off
  - Flash — CH4 — Off
  - Armed — CH5 — Off
- ALARM-command — Preferably FB **OLED display**
  - Delayed simulat — CH1 — Released
  - Direct simulate — CH2 — Released
  - Arm — CH3 — Released
  - Flash — CH4 — Released
  - Disable Z4 — CH5 — Released
  - Disable Z5 — CH6 — Released
  - Dis-Arm — CH7 — Released
  - Disable Z6 — CH8 — Released
- ALARM-triggers — FC **VMB7IN**
  - PIR Z1 delayed — CH1 — Released
  - PIR Z2 delayed — CH2 — Released
  - PIR Z3 delayed — CH3 — Released
  - PIR Z4 direct — CH4 — Locked
  - PIR Z5 direct — CH5 — Released
  - PIR Z6 direct — CH6 — Released
  - Keypad NO — CH7 — Released

Buttons to activate / de-activate a particular zone

Button to de-activate the alarm (if keypad driven, then it should be replaced by the corresponding channel(s) of a VMB7IN)

Button to switch off the flash light (remains on to testify siren activity)

Button to activate the alarm, should be replaced by corresponding channel(s) of a button from any input module (VMBGPxxx/ VMBELxxx / VMB7IN or VMB8PBU) where it is recommended to request a long press before action initiation

Buttons to simulate a direct PIR motion detect, should be replaced by corresponding channel(s) of a VMB7IN

Button to simulate a delayed PIR motion detect, should be replaced by corresponding channel(s) of a VMB7IN

Initiator | **Action ^** | **Subject**

FA. ALARM-actions. Buzzer (CH1)
- FB. ALARM-command. Arm (CH1) | 809. Cancel forced off | FA. ALARM-actions. Buzzer (CH1)
- FC. ALARM-triggers. Keypad NO (CH7) | 806. Forced off | FA. ALARM-actions. Buzzer (CH1)
- FB. ALARM-command. Dis-Arm (CH2) | 806. Forced off | FA. ALARM-actions. Buzzer (CH1)
- FB. ALARM-command. Arm (CH1) | 503. Non-restartable delayed on 1s & 18s | FA. ALARM-actions. Buzzer (CH1)
- FC. ALARM-triggers. PIR Z3 delayed (CH3) | 407. Non-restartable timer 19s | FA. ALARM-actions. Buzzer (CH1)
- FC. ALARM-triggers. PIR Z2 delayed (CH2) | 407. Non-restartable timer 19s | FA. ALARM-actions. Buzzer (CH1)
- FC. ALARM-triggers. PIR Z1 delayed (CH1) | 407. Non-restartable timer 19s | FA. ALARM-actions. Buzzer (CH1)

FA. ALARM-actions. Siren (CH2)
- FA. ALARM-actions. Armed (CH5) | 808. Forced off while initiator is open | FA. ALARM-actions. Siren (CH2)
- FA. ALARM-actions. PIR direct (CH3) | 504. On when initiator closes, delayed off when initiator opens 1min30s | FA. ALARM-actions. Siren (CH2)

FA. ALARM-actions. PIR direct (CH3)
- FA. ALARM-actions. Armed (CH5) | 808. Forced off while initiator is open | FA. ALARM-actions. PIR direct (CH3)
- FC. ALARM-triggers. PIR Z6 direct (CH6) | 104. Momentary (follow) | FA. ALARM-actions. PIR direct (CH3)
- FC. ALARM-triggers. PIR Z5 direct (CH5) | 104. Momentary (follow) | FA. ALARM-actions. PIR direct (CH3)
- FC. ALARM-triggers. PIR Z4 direct (CH4) | 104. Momentary (follow) | FA. ALARM-actions. PIR direct (CH3)
- FC. ALARM-triggers. PIR Z3 delayed (CH3) | 503. Non-restartable delayed on 19s & 1s | FA. ALARM-actions. PIR direct (CH3)
- FC. ALARM-triggers. PIR Z2 delayed (CH2) | 503. Non-restartable delayed on 19s & 1s | FA. ALARM-actions. PIR direct (CH3)
- FC. ALARM-triggers. PIR Z1 delayed (CH1) | 503. Non-restartable delayed on 19s & 1s | FA. ALARM-actions. PIR direct (CH3)

FA. ALARM-actions. Flash (CH4)
- FB. ALARM-command. Flash (CH4) | 102. Off | FA. ALARM-actions. Flash (CH4)
- FA. ALARM-actions. Siren (CH2) | 101. On | FA. ALARM-actions. Flash (CH4)

FA. ALARM-actions. Armed (CH5)
- FB. ALARM-command. Arm (CH1) | 503. Non-restartable delayed on 22s & continuous | FA. ALARM-actions. Armed (CH5)
- FC. ALARM-triggers. Keypad NO (CH7) | 102. Off | FA. ALARM-actions. Armed (CH5)
- FB. ALARM-command. Dis-Arm (CH2) | 102. Off | FA. ALARM-actions. Armed (CH5)

FC. ALARM-triggers. PIR Z3 delayed (CH3)
- FB. ALARM-command. Disable Z3 (CH7) | 605. Lock/unlock channel | FC. ALARM-triggers. PIR Z3 delayed (CH3)

FC. ALARM-triggers. PIR Z4 direct (CH4)
- FB. ALARM-command. Disable Z4 (CH5) | 605. Lock/unlock channel | FC. ALARM-triggers. PIR Z4 direct (CH4)

FC. ALARM-triggers. PIR Z5 direct (CH5)
- FB. ALARM-command. Disable Z5 (CH6) | 605. Lock/unlock channel | FC. ALARM-triggers. PIR Z5 direct (CH5)

FC. ALARM-triggers. PIR Z6 direct (CH6)
- FB. ALARM-command. Disable Z6 (CH8) | 605. Lock/unlock channel | FC. ALARM-triggers. PIR Z6 direct (CH6)