

Airco Logic					A1 Low	A1 Medium	A1 High	A1 Heath	A1 VR	A2 Low	A2 Medium	A2 High	A2 Heath	A2 VR	Inkom t°	Keuken t°	Meeting t°	P Airco
initiators & conditions		what to do then			19 Ch1	19 Ch2	19 Ch3	19 Ch4	19 Ch5	21 Ch1	21 Ch2	21 Ch3	21 Ch4	21 Ch5	128 Ch34	131 Ch34	133 Ch34	8 Ch2
P Inkom	Alarm 1	mode H	<	25,0°C	set heating mode			104					104		121	121	121	
P Inkom	Alarm 2	mode C	>	25,0°C	set cooling mode										122	122	122	
P Inkom	Alarm 3		<	15,0°C	activate power relay + keuken airco									104				105
FB Welcome	16 Ch4				activate power relay													105
P Meeting	Alarm 1		<	21,0°C	set low speed			104										
P Meeting	Alarm 2		<	20,0°C	set medium speed				104									
P Meeting	Alarm 3		>	25,5°C	set low speed			104										
P Meeting	Alarm 4		>	26,5°C	set medium speed				104									
P Meeting	Airco 1	Toggle	=	ON	activate airco				103									
P Meeting	Pump		=	ON	thermostat request low speed			104										
P Keuken	Alarm 1		<	21,0°C	set low speed					104								
P Keuken	Alarm 2		<	20,0°C	set medium speed						104							
P Keuken	Alarm 3		>	25,5°C	set low speed					104								
P Keuken	Alarm 4		>	26,5°C	set medium speed						104							
P Keuken	Airco 2	Toggle	=	ON	activate airco									103				
P Keuken	Pump		=	ON	thermostat request low speed					104								
T Keuken	Alarm L		<=	18,0°C	set high speed (too low)							104						
T Keuken	Alarm H		>=	28,0°C	set high speed (too high)							104						
Airco 1	19 Ch5		=	OFF	inhibit until airco activated			703	703	703	703	<===						
Airco 2	21 Ch5		=	OFF	inhibit until airco activated					703	703	703	703	<===				
103	toggle																	
104	momentary																	
105	momentary (old module)																	
121	heating mode																	
122	cooling mode																	
703	inhibit while open																	

The image shows two control panels for a heater and a cooler. The heater panel on the left has a red thermometer icon and includes a 'Range max.' dropdown set to 23.0, and setpoint buttons for 'Confort' (22.0), 'Day' (21.0), 'Night' (15.0), and 'Safe' (5.0). The cooler panel on the right has a blue thermometer icon and includes a 'Range max.' dropdown set to 27.5, and setpoint buttons for 'Standby' (24.0), 'I' (25.0), 'R' (26.0), and 'H' (27.0). Both panels have a 'Range min.' dropdown set to 5.0.

